

ALCOM
Quality Lifestyle

Caller ID Telephone



AT6083
USER'S MANUAL

INTRODUCTION

Thank you for purchasing our newest Caller ID phone. This manual is designed to familiarize you with this phone. To get the maximum use from your new phone, we suggest that you read this instruction manual carefully before using.

SAFETY INSTRUCTION

When using your telephone equipment, the following basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons:


1. Read, understand and follow all warnings and instructions
2. Unplug the product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a soft damp cloth for cleaning.
3. Do not place this product on unstable surfaces. The product may drop, causing serious damage to the product.
4. Do not overload wall outlets and extension cords as this can result in fire or electric shock.
5. Never push foreign objects of any kind into this product through cabinet slots as they may affect dangerous voltage points or short circuit parts that could result in fire or electric shock. Never spill liquid of any kind on the product.
6. Avoid moving or disconnecting this unit during a heavy storm, as there may be a remote risk of electric shock from lightning and thunder.
7. Unauthorized persons cannot open or service even if there is a defect with the unit. This will void the warranty, please send to service center for any defects.

FEATURES

- FSK/DTMF/ETSI compatible with auto-detection
- 16-digit LCD display
- 99 incoming and 18 outgoing number memories
- 10 two-touch memories
- 16 kinds of ringing tone for selection
- 3 kinds of hold on music for selection
- Do Not Disturb function
- Transfer function between parallel phones (using 2 similar models)
- Pre-dial and edit function
- Redial function
- 3-step lock function and 5 sets of alarm clock
- 16 levels of LCD contrast
- Calculator and key tone function
- Pulse/Tone dialing mode compatible
- 3 levels of hands free volume for selection

- Ringing volume 8 steps for selection
- LCD backlight
- Hands free dialing function
- Ring and in use LED indicator

LOCATION DESCRIPTION



- | | | | |
|--------------|---------|-------------|-----------------------|
| ① LCD | ⑥ DEL | ⑪ RD | ⑯ NUMERICAL KEY |
| ② UP/+ | ⑦ SET | ⑫ H.F | ⑰ LINE |
| ③ DOWN/- | ⑧ CAL | ⑬ RING LED | ⑱ LOCK |
| ④ OUT/× | ⑨ ALM/P | ⑭ ST/RECALL | ⑲ INSERT HANDSET CORD |
| ⑤ IN USE LED | ⑩ FSH/÷ | ⑮ HOLD/RING | |

GETTING STARTED

1. The unit requires 3 X 1.5V AA batteries. Open the battery compartment cover and insert the batteries in the right polarity, then close the cover (Proposal using alkaline battery). There should be time display on the liquid crystal screen after the batteries are inserted.
2. Insert one end of the line cord to the line jack of the base and the other end to the wall outlet of exchanger.
3. Connect the handset and the unit with coiled line.
4. Setting the dialing mode to correct mode according to the directions from your local telecom.
5. Apply for the caller ID from your local telecom office.

RECEIVING A CALL

1. When a call comes, the telephone rings, and LCD displays the seq. number of the call, the date, time, incoming number and the **NEW** icon.
2. If the same number is received again, and the previous call has not been reviewed, the LCD displays **REP** icon.

When the incoming memory is full, the latest incoming number replaces the oldest number in the memory

NOTE: For the phone to display incoming number and other information, you must have an active Caller ID subscription with your local telephone exchange company.

➤ From handset

1. Pick up the handset and talk to the other party.
2. When finished, return the handset to the base.

➤ Switching to H.F. mode

1. When using the handset, press **H.F.** key and return the handset to the base.
2. When finished, press **H.F.** key again.

➤ From H.F. mode

1. When the telephone rings, press **H.F.** key and talk to the caller. For the other party to hear your voice clearly, speak into the speaker from a distance of 32cm or less.
2. When finished, press **H.F.** key again.

NOTE:

Generally telecom transmits the incoming message (eg., Caller ID Info) between the first ring and the second ring. So please answer the phone after the second ring.

MAKING A CALL

➤ From handset

1. Pick up the handset.
2. When you hear the dial tone, dial the desired number.
3. The unit will start to time the conversation after 6 seconds.
4. When finished, return the handset to the base.

➤ **From H.F. mode**

1. Press **H.F.** key
2. When you hear the dial tone, dial the desired number.
3. The unit will start to time the conversation after 6 seconds.
4. When finished, press **H.F.** key again.

➤ **Pre-dialing function**

1. When the handset is on the base, dial the desired number.
2. If there are mistakes, use the **DEL** key to edit.
3. Press **H.F.** key or pick up the handset and the number will be dialed automatically.

➤ **Redial**

1. Pick up the handset or press **H.F.** key,
2. Press **RD** key, the last dialed number will be dialed again

REVIEWING, CALLING BACK AND DELETING INCOMING NUMBERS

➤ **Reviewing**

On-hook state. Press **▲/+** or **▼/-** key to scroll and review the numbers.

➤ **Deleting**

When the desired number is shown, press **DEL** key, the number is deleted.

Press and hold **DEL** key for 3 seconds; all the incoming numbers are deleted.

➤ **Calling back**

1. Scroll to the desired number, press **H.F** key or pick up the handset, and the number is dialed out,
2. Or press **RD** key, LCD displays **PICK UP**, press **H.F** key or pick up the handset, the number is dialed out.
3. Or press and hold **RD** key till **PICK UP** flashing, press **H.F** key or pick up the handset, the number is dialed out. If the long distance code is set, the telephone will add the long distance code ahead the number automatically and then dial back.

PREVENTING FSK MESSAGE TO AUTO-ADJUST REAL TIME

When a FSK message comes, the unit adjusts real time automatically, you can prevent real time auto adjustment as follows:

1. In on-hook state, press and hold **ALM/P** key for 3 seconds, LCD displays **DATE OFF**,
2. Press **ALM/P** key again, LCD displays **DATE ON**,
3. Press **SET** key to quit.

NOTE: **DATE OFF:** Does not allow real time auto adjustment

REVIEWING, CALLING BACK AND DELETING OUTGOING NUMBERS

➤ **Reviewing**

In on-hook state, press **OUT/X** key, then repeat **OUT/X** to review outgoing numbers one by one.

➤ **Calling back**

1. In on-hook state, press **OUT/X** key to review the desired number, then press **H.F.** key or pick up the handset, and the number is dialed out, or
2. Press **RD** key, LCD displays **PICK UP**, press **H.F.** key or pick up the handset, the number is dialed out.

➤ **Deleting**

1. In on-hook state, press **OUT/X** key to scroll to the desired number.
2. Press **DEL** key and the number is deleted, or
3. Press and hold **DEL** key for 3 seconds. All numbers will be deleted.

SETTING MENU

➤ **Setting date & time**

1. In on-hook state, press **SET** key, the value for the year flashes.
2. Press **▲/+** or **▼/-** key to edit the year.
3. Press **SET** key to confirm and enter the next value month setting.
4. Repeat the year setting step to set the month.
5. Repeat the above steps for date and time setting.

➤ **Setting Local Area Code and Long Distance Code**

1. After setting up the date and time, press **SET** key. LCD displays **CODE 0 -----** and the long distance code "0" flashes,
2. Press **▲/+** or **▼/-** key to edit the flashing code from 0 to 9.
3. Press **SET** key to confirm and enter the next flashing code setting.
4. Repeat the above steps for the rest code setting.

➤ **Adjusting LCD Contrast**

1. After setting up the local area code, press **SET** key, LCD display **LCD 08**
2. Press **▲/+** or **▼/-** key to adjust the LCD contrast, total 16 levels can be selected.
3. Press **SET** key to confirm and exit.

Alternatively at on-hook state, press FSH/÷ key to enter LCD contrast setting directly, then press FSH/÷ key continuously to adjust the LCD contrast.

➤ **Setting Alarm Clock**

1. In on-hook state, press **ALM/P** key once, LCD displays **12-00 AL1**,
2. Press **▲/+** or **▼/-** key to select ON or OFF. LCD displays "ALM" icon when the alarm is set to ON.
3. Press **SET** key, value "12" starts to flash.
4. Press **▲/+** or **▼/-** key to set the alarm hour and press **SET** key to confirm and enter alarm minute setting.
5. Press **▲/+** or **▼/-** key to edit alarm minute and press **SET** key to confirm and go to next group alarm clock setting.

6. Repeat the above steps to set additional alarms.

NOTE: The first 3 groups alarm clock will be repeated periodically every day while the last 2 groups alarm clock is effected one time.

SETTING PAGE NUMBER FOR CALL TRANSFER

➤ Setting paging number for phones connected in parallel.

1. In **ON-HOOK** state, press and hold **SET** key, LCD displays **EL--**
2. Key in “ * ” and paging number (example * 1 or * 2), use **DEL** key to edit.
3. Press **SET** key to confirm and exit.
4. To Remove Page number please repeat step 1 and press **DEL**.

CALL TRANSFER BETWEEN PARALLEL PHONES

➤ Transferring an Incoming Call to paralleled phones with Intercom

When a call comes pick up handset or press **H.F.** button from the first unit, then Press “ * ” and paging number(1 or 2) that was set in the second unit, and that unit will ring. Pick up handset or press **H.F.** key on the second unit to have intercom conversation. Outside caller, first unit user and second unit user will be connected with each other in conversation. First unit user may disconnect the call so the second unit user and outside caller can continue the conversation or vice versa.

Important Notes

- Only incoming calls can be transferred using this function.
- Please use same model phones to use the above Call Transfer features. If different model phone is connected in parallel, page number cannot be set and only can transfer calls from that different model phone to the model referred in this manual and intercom during may not be possible in certain cases.
- If the paging number is set, Anti-steal dialing function will not work.
- This feature will work only on regular PSTN networks.
- Any special services starting with “ * ” offered by your Telephone company may not function properly. Please deactivate Call Transfer function before using those special services.

*(Example Phone banking service which prompts you to press “ * ” followed by some number for choosing language etc.)*

ANTI-STEAL DIALING FUNCTION

1. In on-hook state, press and hold **#/=** key for 3 seconds, LCD displays **SPI ON**
2. Press **H.F.** key twice and then
3. Press and hold **#/=** key for 3 seconds again, LCD displays **SPI OFF**,

When the anti-steal is set to ON, users who want to dial using an extension to dial via the same line will hear a “DI-DI, DI-DI” beep continuously and will not be allowed to make a call.

NOTE: If page number is set this function will not work.

SETTING RINGING TONE AND ADJUST RINGING VOLUME

Batteries should be installed in order to hear the ring melody.

There are 16 kinds of ringing tone and ringing OFF for selection:

1. In on-hook state, press once **HOLD/RING** key, LCD displays **ring 02 db8**
2. Press **HOLD/RING** to select the desired ringing or set ring OFF.
3. Press **▲/+** or **▼/-** key to set ringing volume.
4. Press **SET** to confirm and exit.

NOTE: The volume ranges from 1db-8db, with 8db being the loudest. Ring OFF is “**Do Not Disturb**” mode. If the phone is set to this mode, the telephone will not ring when there is an incoming call.

ADJUST HANDSFREE VOLUME

In hands free mode, press **▲/+** or **▼/-** to adjust the handsfree volume, LCD displays the volume level and there are a total of 3 levels.

SELECTING PULSE OR TONE DIALING MODE

1. In on-hook state, press and hold ***/.** key for 3 seconds, LCD displays **P**, then dialing mode is set as Pulse.
2. Press **H.F.** key twice and hold ***/.** key for 3 seconds again, LCD displays **T**, then dialing mode is set as Tone.

HOLD ON MUSIC

➤ Hold music selection

There are 3 kinds of hold music for selection

1. At off-hook or hands free state, press **HOLD/RING** key
2. Press **OUT/X** key to select the desired hold music. It plays the music at same time.
3. Press **▲/+** or **▼/-** key to select the 4 steps volume of hold music.
4. Press **HOLD/RING** key to quit.

➤ When talking over handset, press **HOLD/RING** key to enter the hold mode and the hold music is sent out. In hold mode

1. Press **HOLD/RING** key to release hold mode and continue to talk over handset, or
2. Hang up handset, it enters hands-free hold mode.

➤ When talking at hands-free mode, press **HOLD/RING** key to enter the hold mode and the hold music is sent out. In hold mode

1. Pick up handset to talk over handset, or
2. Press **H.F.** key to quit hold mode and talk at hands-free mode.

TWO TOUCH MEMORY OPERATION


➤ Store the number in two-touch memory

1. Pre-dial the desired number or checking incoming and outgoing number that you want to store.
2. Press **ST/RECALL** key
3. Press one of digit keys (0-9)

➤ Make a call from two-touch memory

In off-hook or at hands-free state, press **ST/RECALL** key + digit key (0-9) key, the relevant number will be dialed out.

LOW BATTERY DETECTION

When the voltage is lower than 3.9V, LCD displays “” icon to remind the user to replace the batteries.

LCD BACKLIGHT FUNCTION

The backlight is turned on when receiving an incoming call, dialing, pressing any key or in MUSIC HOLD mode. It will fade off if the telephone is left idle for 10 seconds.

NOTE: If batteries are not installed, there will be no LCD backlight function.

FLASH FUNCTION

When on a first line Press **FSH/÷** button to answer call waiting line (second call) .

Press **FSH/÷** button again to get back to the first line.

LOCK

Turn the key to yellow point, all numbers are locked except emergency numbers 110, 119, 120, 122, 911, 115, 113 and 118.

Turn the key to green point, all numbers starting with “0” are locked.

Turn the key to red point, all numbers are allowed to be dialed out.

BABYCALL FUNCTION

At on-hook state, press and hold **RD** key for 3 seconds to come into baby call function setting. LCD displays **BABYCALL OFF**, press **RD** key to set it ON, press **SET** key. LCD displays NO CODE (or the preset baby call number, press **DEL** key to cancel), input baby call number using numerical key and press **SET** key to confirm.

After set

baby call function to ON state, press any key except **RD** key or pick up handset or press **H.F** key will dial the baby call number automatically 32 times.

When baby call function is ON state, you can still answer the incoming call or parallel call by handset.

NOTE: If you don't use the function, enter baby call function setting as per above operation and select **BABYCALL OFF**, press **SET** key to confirm.

KEY TONE

Batteries should be installed in order to hear the Key tone.

1. In on-hook state, press and hold **CAL** key 3 seconds, key tone is active when hearing "di" voice.
2. Press and hold **CAL** key 3 seconds again, key tone is inactive when hearing "di" voice.

CALCULATOR FUNCTION

In on-hook state, press **CAL** key, LCD displays **0-**, the unit is in calculator state.

The unit is available for operation of "+.-.x.÷", in the calculator state, **#/=** key is used as "=" and the ***./.** key is used as ".", **OUT/×** and **FSH/÷** are used as \times and \div respectively. **▲/+** or **▼/-** key is used as sign of positive or negative.

Eg.1 (10+26) ÷2

1. In on-hook state, press **CAL** key
2. Press **(1, 0, +, 2, 6), ÷, 2, #/=** keys
3. After calculated, press **SET** key to quit.

Eg.2 0.5× 0.6-1

1. In on-hook state, press **CAL** key
2. Press **0, *./., 5, ×, 0, *./., 6, -, 1, #/=** keys
3. After calculated, press **SET** key to quit.

NOTES

Please unplug telephone line and power (if any) when installing / replacing batteries.

TROUBLESHOOTING

? No voice

- + Check if the handset is on the phone or if the line has terminated.

? Receive only

- + Check if P/T mode is properly set.
Check if the unit is locked (use the key to unlock it)

? Rusty batteries or leakage

- + Remove the rust or wipe away the leakage.

? Noise

- + Check if the connector is wet or rusty (Change the connector)

? Ring once then disconnect when receiving a call. Dialing function is still available

- + Check if connector is in a moist environment.
Check if too many extensions are used together or the quality of extension is not good enough
(Change the bad extension)

? **LCD become dim**

- + Check if LCD contrast is properly set or if the batteries are weak. (Adjust LCD contrast, if the LCD is still dim, replace the batteries.)

? **No ring**

- + Check if the RING tone is in the OFF state, reset it.

? **Most of the functions failed**

- + Check if the batteries are strong enough. (Change the batteries)
If batteries are OK (Remove the battery, unplug the lines and reinstall after 10 minutes)

Note: Due to continuous product development all features and specifications are subject to change without prior notice

For more Information on Warranty and Product Support in Singapore please call
(65) 68412668 or Fax to (65) 68412628.

Email: support@alcom.com.sg

Website: www.alcomonline.com