


MODEL:AT3109 Instruction Manual



ILLUSTRATION OF BUTTONS

- 1. HOOK Switch
- 2. WALL Lock
- 3. DIAL Keys
- 4. MUTE Button
- 5. FLASH Button
- 6. REDIAL Button
- 7. Ringer Switch
- 8. KEY Lock



FEATURES

- 1. Flash function
- 2. Redial the last number
- 3. Mute function
- 4. Ringer HI/LOW Switchable

INSTALL ATION

- Open your gift box and take out all the accessories including the base unit. handset, line cord and the coil cord.
- Connect the handset properly to the base unit by the supplied coil cord, and place the handset on the base unit on the hook button.
- Connect the base unit properly to the telephone WALL JACK by the supplied line cord.
- 4. If you can hear the dial tone from the handset, installation is Successful.

OPERATION

1. MAKING A CALL

Pick up the handset, Key in the desired number on the numeric keypad when you hear a dial tone, you may communicate with the other end when he picks up his handset.

2. RECEIVING A CALL

The phone will ring up when it receives a calling signal. Pick up your handset for conversation when it is ringing. Put back the handset properly to hang up after your conversation is completed.

3. FLASH FUNCTION

Press the FLASH button during a conversation to disconnect the call and get a new dialing tone to make another call or redial the last number.

FLASH button is also used to access a Call Waiting Line(2nd call). Press FLASH button again to toggle between the two calls.

4. REDIAL FUNCTION

In case the number you called is busy, press FLASH and then press REDIAL, the number you dialed last will be dialed out again automatically. This operation can be repeated.

5. MUTE FUNCTION

When you are in a conversation with another party, and you want them not to hear you for a while, press and <u>HOLD</u> MUTE button and the other party will not hear you, <u>RELEASE</u> MUTE button to talk to the other party.

6. RINGER SWITCH

There is a RINGER Switch on back of the base unit,
HI: the highest ringer volume. LO: the lowest ringer volume.

7. LOCK

There is a 2 position mechanical lock on back of the

base unit

Red: unlock- You can dial any phone numbers.

Green: Lock all- You can't dial any telephone numbers.

Note: Due to continuous product development All features and specifications are subject to change without prior notice

For more Information on Warranty and Product Support in Singapore please call (65) 68412668 or Fax to (65) 68412628.

Email: support@alcom.com.sg

Website: www.alcomonline.com