


## MBP15 - Quick Start Guide

For a full explanation of all features and instructions, please refer to the User's Guide.


### 1 Setting up your digital baby monitor

#### A Removing the covers




- Turn the battery cover screws 90 degrees in a counterclockwise direction.
- Lift off the battery covers.

#### B Installing the batteries for the Baby unit




- Use only AA non-rechargeable batteries. The baby unit has no charging function!
- Insert the batteries as shown, replace the battery cover and turn the battery cover screw 90 degrees in a clockwise direction.

#### C Installing the batteries for the Parent unit














- Do not install non-rechargeable batteries! Use only AAA rechargeable batteries of the same type.
- Insert the batteries as shown, replace the battery cover and turn the battery cover screw 90 degrees in a clockwise direction.

#### D Connecting the power supplies



- Only use the enclosed adapters (6V DC/300mA). Charge the parent unit for at least 15 hours.

## 2 Basic operation of the keys

Parent unit		
	ON/OFF button	Press to switch on the unit. Press and hold to switch off the unit.
	UP/DOWN buttons	Press to increase/decrease the volume level. Press to scroll through the menu options.
	TALK button	Press and hold to talk to your baby.
	MENU button	Press to enter the main menu. Press to go back one level or exit to previous menu.
	CONFIRM button	Press to confirm a selection.
Baby unit		
	ON/OFF button	Press to switch on the unit. Press and hold to switch off the unit.
	UP/DOWN buttons	Press to increase/decrease the volume level.
	PAGING button	Press and hold for 2 seconds to start paging and locate parent unit.
	PLAY/PAUSE button	Press to play or pause a lullaby.
	LULLABY button	Press to change a lullaby.
	NIGHT LIGHT button	Press to switch the night light on or off.

## 3 General Information

### If your product is not working properly...

1. Read this Quick Start Guide or the User's Guide.
2. Visit our website: [www.motorola.com](http://www.motorola.com)
3. Contact Customer Service at 0845 218 0890 in the UK.



Manufactured, distributed or sold by Binatone Electronics International LTD., official licensee for this product. MOTOROLA and the Stylized M Logo, and other Motorola trademarks and trade dress are owned by Motorola, Inc. and are used under license from Motorola, Inc. MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. All other product or service names are the property of their respective owners.  
© Motorola, Inc. 2009. All rights reserved.

Printed in China  
Version 1.0

