


## MBP16 - Quick Start Guide

For a full explanation of all features and instructions, please refer to the User's Guide.

### 1. Setting up your digital baby monitor




#### 1.1 Baby unit power supply

1. Insert the small plug of the power adapter into the side of the baby unit, as shown.
2. Connect the other end of the power adapter to the mains socket.


1

### 1.2 Parent unit battery installation



1. Turn the belt clip so that it is in the hanging position.
2. Slide off the battery compartment cover.
3. Insert the supplied rechargeable batteries, and fit the battery pack into the compartment, as shown.
4. Reattach the battery compartment cover.
5. Insert the small plug of the power adapter into the side of the parent unit.
6. Connect the other end of the power adapter to the mains socket.
7. The Charging Indicator comes on.

### 1.3 Belt clip on parent unit and baby unit



1. On normal state, the belt clip can be hanged on the belt directly.
2. Lift up the belt clip and rotate 180°, then the parent unit or baby unit could stand on the desk.

### 2. Basic operation of the keys

Parent unit	
	In idle mode: Press to access the main menu. In menu mode: Press to access the sub-menu, or confirm the settings.
	In menu mode: Press to cancel settings and back to the previous level.
	In idle mode: Press to increase the speaker volume. In menu mode: Press to view the previous menu item.
	In idle mode: Press to decrease the speaker volume. In menu mode: Press to view the next menu item.
	In idle or menu mode: Press and hold to power on/off the parent unit.
	In idle or menu mode: Press and hold to talk back with baby unit. Release to quit the talk mode.
Baby unit	
	Press to increase the speaker volume.
	Press to decrease the speaker volume. Press and hold to reset settings to default.
	Press to turn on/off the nightlight.
	Press to select the lullaby and start playing the selected lullaby. During lullaby playing, press to select and play the other lullabies.
	Press and hold to power on/off the baby unit.
	Press to play the lullaby. Press again to stop playing.

2

### 3. General information

If your product is not working properly...

1. Read this Quick Start Guide or the User's Guide.

2. Contact Customer Service in the

Singapore +65 68412668  
Email support@alcom.com.sg

3

Manufactured, distributed or sold by Binatone Electronics International LTD., official licensee for this product. MOTOROLA and the Stylized M Logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC. and are used under license. All other trademarks are the property of their respective owners.  
© 2012 Motorola Mobility, Inc. All rights reserved.

4