

User's Guide

Model EX30044



Desktop Corded Phone with Caller ID* & Speakerphone



visit our website:
www.thehomephones.com

Model EX30044
P/N: 830044-4103
Version 2 11/2010
Printed in China
©2010 CCT Tech Global Limited

is a trademark of
The General Electric Company
and is under license by
CCT Tech Global Limited,
Central, Hong Kong

INTRODUCTION

Your Caller ID phone stores and displays specific information, provided by your local telephone company, to subscribers of Caller ID or similar caller identification services.

Your Caller ID phone enables you to:

- Identify callers before you answer the phone.
- View the time and date of each incoming call.
- Record up to 68 Caller ID messages sequentially.

MAIN FEATURES

- FSK/DTMF Caller ID auto detect
- Incoming call log records up to 68 calls
- Outgoing call log records up to 15 last dialed numbers
- 10 two-touch memories
- On hook pre-dialing
- Prefix Code
- Redial
- Pulse or Tone dialing mode
- Mute function
- Speakerphone


To get the most from your new phone, please read through this user's guide.

SHORT GLOSSARY OF TERMINOLOGY USED IN THIS MANUAL

Hook switch. The part of the base that pops up to activate the phone line when the handset is lifted from the base.
Off-hook. A term used to describe the phone in its active mode; when the handset is off the base cradle or when the **SPEAKER** button is pressed.
On-hook. A term used to describe the phone in its inactive mode.

PARTS CHECKLIST


Your package includes the following items:



NOTE: If you find any of the parts missing, please contact the store where this product was purchased.

TELEPHONE JACK REQUIREMENTS

To use this phone, you need a RJ11C type modular telephone jack (similar to the one pictured here), installed in your home. Call your local phone company to get one installed.



INSTALLATION

CAUTION: Disconnect the phone cord from the wall outlet before installing or replacing the batteries.

- Never install telephone wiring during a lightning storm.
- Never touch un-insulated telephone wires or terminals, unless the telephone line has been disconnected at the network interface.
- Read caution when installing or modifying telephone lines.
- Never install telephone jack in wet location unless the jack is specifically designed for wet locations.
- Temporarily disconnect any equipment connected to the phone, such as faxes, other phones or modems.


INSTALLING AND REPLACING THE BATTERIES

Your Caller ID phone uses 3 AA-Size alkaline batteries for receiving and storing Caller ID records and for storing the numbers you use frequently.

IMPORTANT: If you are not going to use the telephone for more than 30 days, remove the batteries.

BATTERY

- If the telephone line cord is connected, disconnect it from the base unit.
- Carefully turn the phone over and open the battery compartment by pushing on the battery cover and sliding it away from the unit.
- Insert 3 AA-size alkaline batteries (not included) as shown on the diagram in the battery compartment.
- Snap the battery compartment door back into place.
- If the line cord was previously connected, reattach it to the unit and check your memory locations.



INSTALLING THE PHONE


Your phone should be placed on a level surface, such as a desk or table top, or you can mount it on a wall.

- Connect the handset.
- Connect the telephone line.




WALL MOUNTING



- Rotate the wall mounting knob as shown in the following layout:



- Install the base unit to the wall and then plug one end of line cord into the junction box and the other end into the modular telephone line jack marked "T".
- Fix the telephone in the wall as shown in the following layout.



OPTIONS MENU



SETTING THE PHONE


There are 4 options to set:

- SEL 1 DATE** Date and Time Setting.
- SEL 2 PCODE** Pcode is a prefix code that user may add to the front of the number before dialing.
- SEL 3 T-P** Select the dialing mode. This is dependent on the telephone company you are connected to.
- SEL 4 FLASH** Timing setting. This timing allows user to momentarily access telephone services (such as call waiting) when FLASH button is pressed.


SETTING DATE/TIME




SETTING PCODE



SETTING TONE/PULSE





SETTING FLASH




PHONE OPERATION

RECEIVING A PHONE CALL



MAKING A PHONE CALL




CONTRAST LEVEL ADJUSTMENT

Press the MUTE button to adjust the display contrast level when the telephone is in on-hook states.

P=>T DIAL MODE

In PULSE dialing mode, press[*] button to access TONE service.

REDIAL



MUTE

In off-hook state press the MUTE button to activate the mute function. When MUTE is on, the MUTE indicator will show on the screen. Press the MUTE button to exit mute function and resume normal conversation.



CALLER ID FEATURES

Caller ID (CID) is a service available from your local telephone company. For Caller ID to work on this system, you must subscribe to Caller ID service. This unit can receive caller ID without any setting. The Caller ID information may include the phone number, date and time.

REVIEWING INCOMING CALLS




DIAL BACK A CALLER ID NUMBER




REVIEWING OUTGOING NUMBERS



DIAL BACK AN OUTGOING NUMBER



DELETING A CALLER ID NUMBER



MEMORY OPERATIONS

STORING A TELEPHONE NUMBER




STORING AN INCOMING CALL NUMBER



STORING OUTGOING NUMBERS INTO MEMORY



DIALING A MEMORY LOCATION



DELETING A MEMORY LOCATION



TROUBLESHOOTING TIPS

No Dial Tone

- Check all connections are secure and not damaged.
- Make sure the hook switch is fully extended when handset is lifted from cradle.

No Display

- Replace the batteries.
- Check for proper battery installation.

No Information is Shown After the Phone Rings

- Make sure you have subscribed to Caller ID service from your local telephone company?
- Be sure to wait until the second ring before answering a call.

Phone Dials in Pulse with Tone Service

- Make sure T/P DIAL MODE is set to TONE DIAL.

Phone Will not Dial Out with Pulse Service

- Make sure T/P DIAL MODE is set to PULSE DIAL.

Phone Does Not Ring

- You may have too many extension phones on one line. Try unplugging some extension phones.
- Check dial tone, see troubleshooting tips for no dial tone.

Incoming and Outgoing Voice Volume Low

- Check if other phones are off hook at the same time. If so, this is a normal condition. Volume drops when additional phones are used at once.
- Check the handset receiver or speaker volume.

GENERAL PRODUCT CARE

To keep your phone in good operating condition, follow these guidelines:

- Avoid placing near heating appliances and devices that generate electrical noise (for example, motors or fluorescent lamps).
- DO NOT expose to direct sunlight or moisture.
- Avoid dropping and other rough treatment.
- Wipe with a soft cloth.
- Never use a strong cleaning agent or abrasive powder as this will damage the finish.
- Retain the original packaging in case you need to ship it at a later date.

Used equipment must be disposed of in compliance with current environment protection regulations. You should return it to your reseller or dispose of it in an approved recycling center.